



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® FINISHING KIT
83 PIECES

Kit Number
F187 (USE WITH HTD187)

Model Fitment
2012 DYNA® SWITCHBACK™

NOTE

Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered. Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTD100	1	Under triple tree at brake line junction
HTD181	1	SILICONE over small 12-point bolt on rear caliper
HTD200	1	Over bolt on rear shifter rod lever behind the inner primary cover
	1	Left side inner primary cover to engine case mounting bolt (below ignition coil)
HTD220	2	Recessed allen bolts in front of oil filter
	4	Recessed allen bolts on both sides of front fork leg sliders that support front fender
	2	SILICONE over recessed allen bolts on backside of front turn signal lights
	4	SILICONE in recessed allen bolts on sides of upper and lower triple trees
	1	SILICONE over recessed allen bolt at the bottom of front fork leg
HTD265	4	Round torx bolts on both sides of upper and lower triple trees
	2	Rear belt guard mounting bolts
HTD311	4	On exhaust support arm mounting bolts
	1	Left side on shift lever bolt
	1	SILICONE on front master cylinder banjo fitting on right side of handlebars
	4	Inner front fender mounting nuts
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	1	SILICONE on the mounting bolt in the middle of the air cleaner cover
	2	SILICONE over bottom shock bolts
	1	SILICONE over end of shifter lever peg
HTD555	11	Detachable windshield mounting screws
	2	SILICONE over hex bolts underneath lower triple tree
	2	SILICONE over hex bolts on rear master cylinder underneath exhaust pipe
HTD600	1	SILICONE over exhaust clamp stud
	2	SILICONE over black allen bolts on rear brake caliper
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)

LIFETIME GUARANTEE IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS, OR DISCOLORS WE REPLACE IT FREE!