

FDELUXE: FINISHING KIT FOR TWIN CAM SOFTAIL® DELUXE® KIT  
INCLUDES 147 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTD100	1	Under triple tree at brake line junction
	2	Front of frame inner regulator mounting bolts
	2	Left side floorboard to bracket mounting bolts
	2	Right side floorboard to bracket mounting bolts
HTD181	4	Over small 12-point bolts on front and rear brake calipers
HTD200	1	Left side top of shift lever bolt
	4	On the handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
HTD211	2	Left side floorboard to bracket mounting nuts
	2	Right side floorboard to bracket mounting nuts
HTD220	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
	1	Snip off stem of mushroom cap, file it evenly down and <b>SILICONE</b> it over the casing hole in front of the clutch release cover on transmission housing
	1	Right side <b>SILICONE</b> in empty casing hole in transmission housing behind clutch release cover
	2	<b>SILICONE</b> in holes in top triple tree on steering stem of front fork
HTD265	5	On front brake disc mounting bolts
	4	On front fork panel over round torx bolts on both sides of upper and lower triple tree bolts
	1	<b>SILICONE</b> in the center of the choke knob ( <b>Carbureted models only</b> )
HTD282	7	Large 12-point bolts on front and rear brake calipers, 4 on the front and 3 on the rear
HTD300	3	Exhaust bracket that mounts to swingarm mounting bolts
	2	On the right side over the nuts on the bottom of fork leg at the front axle
HTD311	1 of 7	On left side on engine case bolts under cylinder heads
	4	On the inner front fender, covers the nuts on the inside
	1	Top of kickstand bolt
	1	Replace acorn on left side shifter rod with supplied ½" nut and push on

- Hot Topper®
- 3 Replace acorns on left side rear belt guard with supplied ½” nuts and push on  
Hot Toppers®
- 2 Right side rear exhaust mounting bolts in between exhaust pipes
- 2 Both sides fork tube drain plug
- 1 **SILICONE** on brake master cylinder banjo fitting on the right side of  
handlebars
- HTD343 1 Left side swingarm mounting nut
- HTD344 1 Left side lower motor mount bolt underneath footboard behind kickstand
- 2 On both sides on the rear shock absorber mounting bolts
- HTD355 5 Left side over rear sprocket mounting bolts and washers
- HTD365 5 Over rear brake disc mounting bolts
- 1 **SILICONE** on the mounting bolt in the middle of the air cleaner cover
- HTD420 2 **SILICONE** over left and right side rear footpeg bracket mounting bolts
- 10 **SILICONE** over torx bolts on rear fender struts
- HTD500 2 Rear axle adjuster bolts
- 1 Right side rear brake pedal mounting bolt at pivot
- 1 Left side front gas tank mounting bolt
- 1 Under the lower triple tree on the front fork
- HTD555 3 front & rear brake line to caliper mounting bolts as well as rear  
Master cylinder banjo bolt
- 4 **SILICONE** over exhaust mounting nuts on backside of exhaust bracket
- HTD600 1 Right side replace acorn on front gas tank mount with supplied 9/16” nut then  
push on Hot Toppers®
- 1 of 2 Top left and right side engine to transmission bolts
- 3 Left side nuts and studs top engine mount, horn and enrichener cable bracket
- 3 **SILICONE** over exhaust nuts on right side (**SILICONE REQUIRED  
although our cover slides over nut, the stud prevents total  
engagement so add some SILICONE**)
- HTD708 1 Conversion kit!! Replace button torx screws on brake and clutch housings with  
supplied allen bolts and press on Hot Toppers®
- HTD723 1 Conversion kit!! Replace button torx screws on derby and inspection covers  
with supplied allen bolts and press on Hot Toppers® (**IMPORTANT:  
when replacing each button torx screw with allen bolt, make sure  
the allen bolt is the exact length of the button torx bolt. Also be  
sure to only change one bolt at a time so the gaskets do not loosen**)
- HTD777 1 Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over  
left side hex axle nut and the smooth sleeve over right side smooth axle  
rod

#### ADDITIONAL OPTIONS NOT INCLUDED

- HTD100 2 **SILICONE** above the air cleaner on the top carburetor screws
- HTD560 1 Windshield screw cover kit that fits all Harley Davidson®

HTD600

1

detachable lexan windshields (9-HTD555)  
**SILICONE** over acorn nut on horn cover