

FDEUCE: FINISHING KIT FOR TWIN CAM SOFTAIL® DEUCE®  
INCLUDES 121 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTD100	1	Brake line junction mounting bolt under triple tree
HTD181	4	Over small 12-point bolts on front and rear brake calipers
HTD200	4	On the handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
	3	<b>SILICONE</b> on front & rear brake line to caliper mounting bolts as well as rear master cylinder banjo bolt
HTD211	1	Right side on the backside of the brake pedal
HTD220	4	<b>SILICONE</b> in the center of bolts on the front of the rear fender struts
	1	Snip off stem of mushroom cap, file it evenly down and <b>SILICONE</b> it over the casing hole in front of the clutch release cover on transmission housing
	1	Right side <b>SILICONE</b> in empty casing hole in transmission housing behind clutch release cover
HTD265	5	Front brake disc mounting bolts
		(NOTE: Order 5 more of you bike has dual front discs)
	4	<b>SILICONE</b> on the inner front fender, covers the bolts on the inside
	1	<b>SILICONE</b> in the center of the choke knob (Carbureted models only)
HTD282	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear
HTD300	2	Right side on the rear footpeg to exhaust bracket
HTD311	2 of 8	On left side on engine case bolts under cylinder heads
	1	Top of kickstand bolt
	1	Left side shift lever bolt
	3	Replace acorns on left side rear belt guard with supplied ½" nuts and push on Hot Toppers®
	1	Replace acorn on left side shifter rod with supplied ½" nut and push on Hot Topper®
	2	On right side exhaust mounts between the pipes
	1	<b>SILICONE</b> on brake master cylinder banjo fitting on the right side of

handlebars

- HTD344 2 Lower handlebar riser bolts below the upper fork leg triple tree  
1 Left side lower motor mount bolt underneath footboard behind kickstand  
1 On right side on the rear shock absorber mounting bolt  
2 **SILICONE** on the backside of the lower triple tree mounting bolts
- HTD355 5 Left side over rear sprocket mounting bolts and washers (**IMPORTANT: Check clearance between the engaged part and the belt guard mounting nut on one piece prior to installing all 5**)
- HTD365 5 Over rear brake disc mounting bolts  
1 **SILICONE** on the mounting bolt in the middle of the air cleaner cover
- HTD500 4 Over footpeg mounting bolts  
2 Rear axle adjuster bolts  
1 Right side rear brake pedal mount at pivot  
1 Right side headlight mount  
1 Left side front gas tank mount  
1 Under the lower triple tree on the front fork
- HTD600 1 Right side replace acorn on front gas tank mount with supplied 9/16" nut then push cover over  
4 Footpeg mounting nuts  
1 of 2 Top left and right side engine to transmission bolts  
3 Left side nuts and studs top engine mount, horn and enrichener cable bracket  
1 Left side on headlight mount replace acorn with supplied 9/16" nut then push cover over  
3 **SILICONE** over exhaust nuts on right side (**SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE**)
- HTD708 1 Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
- HTD723 1 Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® (**IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen**)

**ADDITIONAL OPTIONS NOT INCLUDED**

- HTD100 1 **SILICONE** on brake line clamp on the backside upper triple tree  
2 **SILICONE** above the air cleaner on the top carburetor screws  
1 **SILICONE** on bolt on the front top of your gas tank to tachometer cover
- HTD220 3 **SILICONE** in the holes on the back side of front caliper
- HTD343 1 Left side swingarm nut
- HTD555 1 Right side **SILICONE** below starter motor cover behind exhaust pipe on black nut and stud  
13 Windshield screw covers that fits all Harley Davidson® detachable lexan windshields 9 on the front and 4 on the sides
- HTD600 1 **SILICONE** over acorn nut on horn cover