

FDY: FINISHING KIT FOR TWIN CAM DYNA SUPER GLIDE®/
DYNA LOW RIDER® KIT
INCLUDES 140 PIECES

HOT TOPPERS® are manufactured to fit American Standard fasteners.

There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email info@hottoppers.com or call our toll free USA number 877-446-8867 with any questions or comments.

HTD100	4 1	Left side electrical panel cover (Only 2 on 2004-up electrical panel cover) Under triple tree at brake line junction
HTD181	4	Over small 12-point bolts on front and rear brake calipers (NOTE: Order 2 more pieces if your bike has dual discs)
HTD200	1 2 2 4 2	Over bolt on rear shifter rod lever behind the inner primary cover Bolts on headlamp bracket visor Right side starter housing mounting bolts behind upper transmission cover On the upper handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down) SILICONE on front and rear brake line to brake caliper mounting bolts
HTD211	2 1 2	Regulator assembly to frame mounting nuts (NOTE: PRE-2004) On the middle oil filter mounting kit bolt Backside of ignition coil bracket enter from right side cover nuts and studs (NOTE: PRE-2004)
HTD220	4 2	In recessed allen bolts on both sides of front fork leg sliders that support front fender SILICONE in holes in top triple tree on steering stem of front fork
HTD265	2 1 5 1 4	Fuel tank center console mounting bolts (NOTE: 2004-up) Over oil hose cover bolt right side of transmission Front brake disc mounting bolts (IMPORTANT: Install one Hot Topper® and rotate tire one complete rotation, make sure the Hot Topper® clears the fork leg. If your bike has dual front discs or if you have a 2004-up Dyna with wheel hub on right side order 5 more pieces) SILICONE in the center of the choke knob (Carbureted models only) SILICONE over round torx bolts on both sides of upper and lower triple trees
HTD282	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear (Order 4 more pieces if your bike has dual discs)
HTD300	2	On right side below cam cover footpeg to frame mounting bolts

- 2 On rear fork/axle adjuster bolts left and right side
- 1 Left side under primary cover rear footpeg to frame mounting bolt
- 2 Left side rear footpeg mounting bolts
- 1 **SILICONE** over hex nut behind electronics box mount
(NOTE: If you have a 2004-up Dyna Low Rider® you will need 4 more pieces for your forward control mounting bolts)

- HTD311 4 On the inner front fender, covers the nuts on the inside
- 3 On exhaust support arm bolts behind transmission clutch release cover
- 2 Right side below ignition switch over black bolts
- 2 Over front gas tank mounting bolt left and right side
- 1 Left side on shift lever bolt
- 1 Replace acorn on left side shifter rod with supplied ½” nut and push on Hot Topper®
- 2 Over rear belt guard mounting bolts
- 2 In front of the cylinders on the backside of the regulator to frame mounting nuts
- 1 **SILICONE** on front master cylinder banjo fitting on right side of handlebars

- HTD344 2 Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts

- HTD355 5 Left side over rear sprocket mounting bolts and washers

- HTD365 5 Over rear brake disc mounting bolts
- 1 **SILICONE** on the mounting bolt in the middle of the air cleaner cover

- HTD420 2 **SILICONE** over torx bolts on rear fender struts

- HTD500 6 Over each footpeg mounting bolt (**Only 4 on Dyna Super Glide®**)

- HTD600 6 Over all footpeg mounting nuts (**Only 4 on Dyna Super Glide®**)
- 1 Pinch bolt nut on front axle on right lower fork slider assembly
- 2 Left side rear footpeg backside mounting nuts (**NOTE: PRE-2004**)
- 3 Right side over exhaust pipe nuts and studs (**SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE**)

- HTD708 1 Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®

- HTD723 1 Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® (**IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen**)

- HTD777 1 Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over the left side hex axle nut and the smooth sleeve on the right side smooth axle rod (**NOTE: If you have a 2004-up Dyna Low Rider® or Dyna Super Glide® you will not need smooth sleeve on right side smooth axle rod**)

ADDITIONAL OPTIONS NOT INCLUDED

- HTD100 2 **SILICONE** above the air cleaner on the top carburetor screws
- HTD200 1 **SILICONE** on right side rear brake line master cylinder banjo bolt below rear

		footpeg behind exhaust pipe
HTD300	4	SILICONE on the right side exhaust to frame mounting nuts and bolts
HTD555	2	SILICONE on the left side of the bottom debris deflector on underside of rear fork mounting bolts
HTD560	1	Windshield screw cover kit that fits all Harley Davidson® detachable lexan windshields (9-HTD555)
HTD600	1	SILICONE over acorn nut on horn cover
HTD820	1	SILICONE on engine oil filler cap