



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® FINISHING KIT 113 PIECES

Kit Number
FFL9 (USE WITH HTD156)

Model Fitment
2008 FLH/FLT MODELS

NOTE

**Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)**

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

**** You might have a few extra pieces left over depending on the model you ride! ****

PART #	QTY	LOCATION OF PART
HTD100	2	Front of bottom saddlebag support arms bolt underneath the saddlebag
	2	Allen bolts on black bracket in front of gas tank above front cylinder (Only for Ultra Classic® Electra Glide®)
HTD200	1	Left side SILICONE on the top of shift lever allen pinch bolt
	1	Over allen bolt on rear shifter rod lever behind the inner primary cover
	1	Front safety bar mounting allen bolt to frame
	2	Right side brake master cylinder
HTD211	2	Left and right side upper rear saddlebag mounting bracket hex bolts
	2	Front of bottom saddlebag support arms hex nut underneath the saddlebag (Only for Ultra Classic® Electra Glide®)
	7	Hex nuts underneath tour pack (Only for Ultra Classic® Electra Glide®)
HTD220	2	Front of engine over recessed allen bolts at oil filter mount
	4	Snip stems and SILICONE over the recessed allen bolts on Brembo brake calipers
HTD265	10	Front brake rotor button torx mounting bolts
	2	On both inner fairing lowers screws that clamp the lowers to the engine guard (Only for Ultra Classic® Electra Glide®)
	4	Left and right side front of saddlebag guard mounts (Only for Ultra Classic® Electra Glide®)
	4	SILICONE over recessed torx bolts on Left and right side fairing support bracket bolts on sides of passing lamp bracket (Only for Ultra Classic® Electra Glide®)
	2	Left and right side on the top saddlebag support bracket smooth sided torx mount bolts (Only for 09 Ultra Classic® Electra Glide®)
HTD282	4	Large 12-point bolts that mount front brake calipers to fork legs
HTD288	8	SILICONE over rocker cover hex/torx bolts, requires a few drops of SILICONE on stem
HTD300	1	Left side front over the allen bolt on stabilizer arm
	1	Motor mount bolt on top front on front cylinder
	1	SILICONE over exhaust bracket hex nut behind rear cylinder above starter
	2	Right side over the hex nuts on the bottom of fork leg at the front axle
	2	Left and right side rear footboard mounting allen bolts



INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTD311	2	Both sides fork tube drain plug
	2	SILICONE over banjo fittings on brake master cylinders (handlebar and behind brake pedal)
	4	Left and right side footboard mounting plate hex bolts near swing arm
HTD365	1	SILICONE on the mounting allen bolt in the middle of the air cleaner cover
	2	SILICONE over ends of heel/toe shift lever pegs
HTD400	2	Left and right side bottom engine guard SILICONE over mounting bolts (All models except for Ultra Classic® Electra Glide®)
	1	SILICONE over the large hex nut on the right side rear brake pedal mount at pivot under the front floorboard
HTD500	2	Left front lower engine mount hex bolt
	3	Motor mount bolts on top of front cylinder
	2	Left side upper motor mount hex bolts above horn under gas tank
	4	Left and right side on the top saddlebag support bracket smooth sided torx mount bolts
	4	Left and right side on smooth sided torx bolts facing rear of bike connecting the saddlebag support bars to the support brackets (Only on 08 models)
	1	SILICONE over black allen bolt behind inner primary where shifter linkage connects
HTD555	2	Left and right side on smooth sided torx bolts on lower rear fender saddlebag support brackets * Bracket mounted onto side of rear fender behind saddlebag (Only on 08 models)
	1	SILICONE over right side hex nut toward rear of transmission cover behind exhaust
HTD600	2	SILICONE on backside of left and right side lower triple tree, top of shocks (small hex bolts)
	2	Front bottom of inner frame hex nuts (behind lower crash bar mounting bolts) (Only for Ultra Classic® Electra Glide®)
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®

**Visit www.hottoppers.com
for up-to-date information!**

LIFETIME GUARANTEE
**IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!**
(WARRANTY EXCLUDES SERVICE WORK)