

FSF: FINISHING KIT FOR TWIN CAM SOFTAIL® STANDARD/ NIGHT TRAIN® KIT  
INCLUDES 137 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTD100	1	Brake line junction mounting bolt under triple tree
	1	Crankshaft position sensor bolt in front of cylinders next to oil filter
HTD181	4	Over small 12-point bolts on front and rear brake calipers
HTD200	1	Over rear shifter rod lever mounting bolt behind the inner primary cover
	4	On the handlebar clamp bolts ( <b>IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down</b> )
	3	<b>SILICONE</b> on front & rear brake line to caliper mounting bolts as well as rear master cylinder banjo bolt
HTD220	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
	1	Snip off stem of mushroom cap, file it evenly down and <b>SILICONE</b> it over the casing hole in front of the clutch release cover on transmission housing
	1	Right side <b>SILICONE</b> in empty casing hole in transmission housing behind clutch release cover
	2	Remove screws from Left and right side top triple tree side panels and <b>SILICONE</b> into empty holes
HTD265	5	Front brake disc mounting bolts ( <b>NOTE: order 5 more of you bike has dual front discs</b> )
	1	<b>SILICONE</b> in the center of the choke knob ( <b>Carbureted models only</b> )
HTD282	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear
HTD300	2	On the right side over the nuts on the bottom of fork leg at the front axle
HTD311	4	On the inner front fender cover the nuts on the inside
	1	Top of kickstand bolt
	1	Left side shift lever bolt
	3	Replace acorns on left side rear belt guard with supplied ½" nuts and push on Hot Toppers®
	1	Replace acorn on left side shifter rod with supplied ½" nut and push on Hot Topper®

	2	Both sides fork tube drain plug
	1	<b>SILICONE</b> on brake master cylinder banjo fitting on the right side of handlebars
HTD344	2	Lower handlebar riser bolts below the upper fork leg triple tree
	1	Left side lower motor mount bolt underneath footboard behind kickstand
	2	On both sides on the rear shock absorber mounting bolts
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	1	<b>SILICONE</b> on the mounting bolt in the middle of the air cleaner cover
HTD420	2	Lower triple tree pinch bolts
	10	<b>SILICONE</b> over torx bolts on rear fender struts
HTD500	4	Over footpeg mounting bolt
	2	Rear axle adjuster bolts
	1	Right side rear brake pedal mount at pivot
	1	Right side headlight mount
	2	Right side exhaust support underneath pipes below footpeg
	1	Left side front gas tank mount
	1	Under the lower triple tree on the front fork
HTD600	1	Right side replace acorn on front gas tank mount with supplied 9/16" nut then push cover over
	4	Footpeg mounting nuts
	1 of 2	Top left and right side engine to transmission bolts
	3	Left side nuts and studs top engine mount, horn and enrichener cable bracket
	1	Left side on headlight mount
	2	<b>SILICONE</b> over exhaust nuts on right side ( <b>SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE</b> )
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD723	1	Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® ( <b>IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen</b> )
HTD777	1	Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over the left side hex axle nut and the smooth sleeve on the right side smooth axle rod

#### ADDITIONAL OPTIONS NOT INCLUDED

HTD100	1	<b>SILICONE</b> on brake line clamp on the backside upper triple tree
HTD211	4	<b>SILICONE</b> on the right side exhaust mounts under the pipes
HTD343	1	Left side swingarm nut
HTD555	1	Right side <b>SILICONE</b> below starter motor cover behind exhaust pipe on black nut and stud
HTD560	1	Windshield screw cover kit that fits all Harley Davidson® detachable lexan windshields (9-HTD555)

HTD600

1

**SILICONE** over acorn nut on horn cover