

EVERYTHING THAT IS HIGHLIGHTED IN GRAY SCALE WAS ALREADY INCLUDED IN STARTER KIT (HTD167)



# INSTRUCTIONS

## THE GENUINE USA MADE HOT TOPPERS® FINISHING KIT 77 PIECES

**Kit Number**  
HTD5HC7

**Model Fitment**  
2007-2008 SOFTAIL® HERITAGE CLASSIC

**NOTE**

Additional installation help available worldwide:  
info@hottoppers.com or talk to a live USA based tech  
toll free 877-446-8867 (USA only)

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTD100	13	Around the primary cover allen bolt
	2	Front of frame regulator mounting allen bolts just above regulator
	2	On front of regulator recessed allen bolts
	6	Right side transmission clutch release cover allen bolts
	10	Right side cam cover allen bolts
	8	Right side lifter cover push rod allen bolts
	6	Right side upper transmission housing cover allen bolts
	1	Brake line junction mounting bolt under triple tree
	1	Left side crankshaft position sensor bolt in front of cylinders next to oil filter
	1	Right side allen bolt on frame down tube above transmission behind engine
HTD181	2	Over small 12-point bolts on front and rear brake calipers
HTD200	1	Left side rear shifter rod lever mounting allen bolt behind the inner primary cover
	4	On the handlebar clamp allen bolts (NOTE: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
	8	Right side transmission housing allen bolts
	1	SILICONE on left side top of shift lever allen bolt
HTD220	4	Left and right side recessed allen bolts on front fork leg sliders that support front fender
	2	On front of engine recessed allen bolts on oil filter mount
HTD265	5	On front brake disc mounting torx bolts
	4	On front fork panel over round torx bolts on both sides of upper and lower triple tree bolts
HTD282	4	Large 12-point bolts on front brake calipers
HTD288	8	SILICONE on rocker cover bolts, requires a few drops of SILICONE on stem
HTD300	2	Right side lower transmission mounting bracket allen bolts (IMPORTANT: Install the 1-HTD311 on the lower engine to transmission mounting bolt prior to installing these HTD300s)
	1	Left side on the frame down tube hex nut behind engine above transmission cover
	2	On the right side over the hex nuts on the bottom of fork leg at the front axle
	1	Left side behind inner primary below upper transmission allen bolt



# INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTD311	5	On left side on engine case hex bolts under cylinder heads
	2	Left and right side fork tube drain plugs
	1	SILICONE on brake master cylinder banjo fitting on the right side of handlebars
	2	Left and right side upper engine to transmission mounting hex bolts
	1	Right side lower engine to transmission mounting hex bolt (IMPORTANT: Install the 1-HTD311 on the lower engine to transmission mounting bolt prior to installing these HTD300s)
HTD342	1	Right front motor mount hex bolt
HTD343	1	Left side front motor mount hex nut
HTD365	1	SILICONE on the mounting torx bolt in the middle of the air cleaner cover
HTD420	6	SILICONE over torx bolts on rear fender struts
	6	SILICONE over left and right side front footboard mounting plate torx bolts
HTD500	2	On left side upper motor mount hex bolts above horn under gas tank
	2	Over each footpeg mounting hex bolt
	1	Right side rear brake pedal mount at pivot (torx bolt)
	1	Left side front gas tank mount hex bolt
	1	Under the lower triple tree above front fender hex bolt
HTD555	9	Covers screws on front of windshield
	2	Front brake line to caliper mounting bolt and rear master cylinder banjo bolt
HTD600	2	Right side exhaust support bracket hex nuts at the middle of frame
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®
HTD733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)

### ADDITIONAL OPTIONS NOT INCLUDED

HTD100	2	SILICONE above the air cleaner on the top carburetor screws
HTD211	4	Right side hex bolts on the underside of exhaust support tube assembly
HTD311	4	On the inner front fender cover the hex nuts on the inside
HTD344	2	Right and left side rear shock hex bolts
HTD343	1	Left side pivot hex nut
HTD355	5	Left side over rear sprocket mounting hex bolts and washers
HTD365	5	Over rear brake disc mounting torx bolts

Visit [www.hottoppers.com](http://www.hottoppers.com)  
for up-to-date information!

**LIFETIME GUARANTEE**  
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,  
OR DISCOLORS WE REPLACE IT FREE!  
(WARRANTY EXCLUDES SERVICE WORK)