

FSPC: FINISHING KIT FOR 2004-UP SPORTSTER® KIT  
INCLUDES 110 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTD100	1	Brake line junction mounting bolt under triple tree
	4	<b>SILICONE</b> the Hot Toppers® onto the 6mm mounting screws on the brake and clutch housings
HTD200	2	Bolts on the top of upper triple tree
	4	On the handlebar clamp bolts ( <b>IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down</b> )
	1	On the right side gas tank mounting bolt
	1	Left side behind filler cap
	2	Rear brake master cylinder and reservoir assembly mounting bolts underneath the middle of the bike
	1	Right side rear belt guard mounting bolt
	1	<b>SILICONE</b> on the left side top of the shifter arm bracket
	1	<b>SILICONE</b> over recessed allen bolt on front of oil filter mount
HTD220	2	On the top of the forward control footpeg mounting bolts
	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
	2	<b>SILICONE</b> over the bolt on upper bracket of steering head bracket assembly ( <b>NOTE: Snip the stem off of the part for the left side</b> )
	1	Cut off ½ of the stem and then <b>SILICONE</b> over the threaded case hole on the front brake caliper ( <b>NOTE: Order 1 more piece if your bike has dual disc</b> )
HTD265	2	Frame to brake master cylinder and reservoir assembly mounting bolts behind the primary cover under the left side rear footpeg
	4	Bolts on both sides of the rear fender struts
	5	Front brake disc mounting bolts ( <b>IMPORTANT: Install one Hot Topper® and rotate tire one complete rotation, make sure the Hot Topper® clears the fork leg</b> ) ( <b>NOTE: Order 5 more pieces if your bike has dual disc</b> )
	2	Left side behind the reservoir assembly for the rear brake master cylinder ( <b>NOTE: The bolt above the cap is friction fit but the one below needs SILICONE</b> )
	2	<b>SILICONE</b> over the front lower left side engine to frame mounting bolts
	1	<b>SILICONE</b> in the center of the choke knob

- 1 **SILICONE** on the front of the lower right side fork pinch bolt  
4 **SILICONE** on the bolts on the sides of the upper and lower triple trees
- HTD282 2 On the front brake caliper to fork leg mounting bolts (**NOTE: Order 2 more pieces if your bike has dual disc**)
- HTD300 2 **SILICONE** over upper front cylinder tie-link bracket to frame bottom side engine mounting nuts  
1 **SILICONE** over lower front cylinder tie-link bracket to frame bottom side engine mounting nut
- HTD311 4 On the inner front fender mounting nuts  
2 On the backside of the regulator to frame black mounting bolts  
4 Right side on the underside of the exhaust bracket mounting bolts  
1 Left side **SILICONE** on the black rubber boot on the front brake caliper  
4 **SILICONE** on the brake line banjo bolts on both front and rear calipers as well as upper brake master cylinder on the top of handlebars and below left side passenger peg on brake master cylinder
- HTD342 1 Over the top of the fork stem bolt
- HTD344 2 Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts
- HTD355 5 Left side over rear sprocket mounting bolts and washers  
1 Front lower left side motor mount bolt, cut out the inside walls of the part and **SILICONE** it over the bolt
- HTD365 5 Over rear brake disc mounting bolts  
2 **SILICONE** over the upper mounting bolts on the top of the rear shock
- HTD420 2 Front of front cylinder tie-link bracket mounting bolts
- HTD500 1 Right side headlight mounting bolt  
1 **SILICONE** on the left side rear brake caliper black mounting pin bolt (**NOTE: Order 1 more piece if your bike has dual disc**)
- HTD555 2 **SILICONE** on the front of the regulator mounting bolts
- HTD600 1 Right side back of lower fork leg pinch bolt  
1 Left side headlight mounting bolt  
2 **SILICONE** over exhaust nuts on right side (**SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement**)
- HTD732 1 Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (**IMPORTANT: When replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen**)
- HTD777 1 (2004-2007) Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over left side hex axle nut and the smooth sleeve over right side smooth axle rod

**OR**

