

FSPSE: FINISHING KIT FOR TWIN CAM SPRINGER® SOFTAIL® KIT
INCLUDES 136 PIECES

HOT TOPPERS® are manufactured to fit American Standard fasteners.

There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email info@hottoppers.com or call our toll free USA number 877-446-8867 with any questions or comments.

HTD100	1	Brake line junction mounting bolt under triple tree
	1	Crankshaft position sensor bolt in front of cylinders next to oil filter
HTD181	2	Over small 12-point bolts on rear brake caliper
HTD200	4	On the handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
	3	SILICONE on front & rear brake line to caliper mounting bolts as well as rear master cylinder banjo bolt
HTD220	1	Snip off stem of mushroom cap, file it evenly down and SILICONE it over the casing hole in front of the clutch release cover on transmission housing
	1	Right side SILICONE in empty casing hole in transmission housing behind clutch release cover
	2	SILICONE into bolt and empty hole in top triple tree fork stem pinch bolt
	1	SILICONE on headlight mounting bolt on bracket to fork
	2	SILICONE over blinker light mounting bolts on front handlebars
HTD265	5	Front brake disc mounting bolts (NOTE: Order 5 more if you bike has dual front discs)
	2	Upper triple tree on sides of front fork legs
	1	SILICONE in the center of the choke knob (Carbureted models only)
HTD282	3	Large 12-point bolts on rear brake caliper
HTD300	2	Right and left side headlight mount
	2	On the right side over mounting bolts on front caliper
	2	Left side front shock slider mounts
HTD311	1 of 7	On left side on engine case bolts under cylinder heads
	1	Top of kickstand bolt
	3	Replace acorns on left side rear belt guard with supplied ½" nuts and push on Hot Toppers®
	1	Replace acorn on left side shifter rod with supplied ½" nut and push on Hot Topper®
	1	SILICONE on brake master cylinder banjo fitting on the right side of handlebars

HTD344	1	Left side lower motor mount bolt underneath footboard behind kickstand
	2	On both sides on the rear shock absorber mounting bolts
	1	Left side inner fork leg mounting bolt
	2	Rear shock absorber mounting bolts
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	1	SILICONE on the mounting bolt in the middle of the air cleaner cover
	2	SILICONE on front fender to fork mounting bolts
HTD420	10	SILICONE over torx bolts on rear fender struts
HTD500	4	Over footpeg mounting bolts
	2	Rear axle adjuster bolts
	1	Right side rear brake pedal mount at pivot
	2	Right side exhaust support bolts
	1	Left side front gas tank mount
	1	On front brake caliper SILICONE on the black guide pin kit bolt
HTD600	2	Right side replace the front fork shock slider acorns with supplied 9/16" nuts and then push the covers over
	1	Right side replace acorn on front gas tank mount with supplied 9/16" nut then push cover over
	4	Footpeg mounting nuts
	1 of 2	Top left and right side engine to transmission bolts
	2	SILICONE over exhaust nuts on right side (SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE)
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD723	1	Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTD770	2	SILICONE over the front axle
	4	Snap black hex sleeves into chrome Hot Toppers®, then slide the slotted sleeve over the left and right side hex axle nuts
HTD820	1	Right side front brake caliper insert, use SILICONE to mount

ADDITIONAL OPTIONS NOT INCLUDED

HTD343	1	Left side swingarm nut
HTD555	1	Right side SILICONE below starter motor cover behind exhaust pipe on black nut and stud
HTD560	1	Windshield screw cover kit that fits all Harley Davidson® detachable lexan windshields (9-HTD555)
HTD600	1	SILICONE over acorn nut on horn cover
HTD820	1	SILICONE on engine oil filler cap

