



# INSTRUCTIONS

**THE GENUINE USA MADE HOT TOPPERS® STARTER KIT  
66 PIECES TO COVER ENGINE, TRANSMISSION AND PRIMARY BOLTS**

**Kit Number**  
HTB147

**Model Fitment**  
2007-UP ALL V-ROD MODELS

**NOTE**

**Additional installation help available worldwide:  
info@hottoppers.com or talk to a live USA based tech  
toll free 877-446-8867 (USA only)**

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

**The V-ROD features metric fasteners. All of the Hot Toppers® in this kit REQUIRE SILICONE!**

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTB100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTB100	2	Right side on starter motor body screws
	2	Right side by thermostat housing (1), Front of rear cylinder (1)
HTB200	12	Rocker box bolts
	14	Primary cover
	13	Cam cover
	3	Clutch cover
	2	Starter motor mount bolts
	7	Right side on water pump cover
	2	Right side on top of thermostat housing
	2	Above rear shifter linkage arm
	1	Left side above engine oil drain
HTB220	2	Snip stems and mount in derby cover
HTB420	2	Left side behind horn, top of left & right side cylinders
HTB500	2	Center of bike behind rear cylinder engine case bolts

**To cover the rest of your exposed nuts and bolts go to [www.hottoppers.com](http://www.hottoppers.com) and print out a complete installation guide for your motorcycle!**

**LIFETIME GUARANTEE  
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,  
OR DISCOLORS WE REPLACE IT FREE!**