



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 173 PIECES

Kit Number
HTBBLKL

Model Fitment
2011-UP SOFTAIL® BLACKLINE

NOTE

**Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)**

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTB100	13	Around the primary cover allen bolts
	6	Over transmission clutch release cover allen bolts
	10	Right side cam cover allen bolts
	8	Right side Lifter cover push rod allen bolts
	6	Right side upper transmission housing cover allen bolts
	2	Front of frame regulator mounting allen bolts
	2	On front of regulator recessed allen bolts
	1	Speed sensor allen bolt on top of transmission housing
	1	Crankshaft position sensor allen bolt in front of cylinders next to oil filter
	2	Recessed allen bolts above regulator
HTB200	8	Right side transmission housing allen bolts
HTB220	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
	2	Front of engine on oil filter mount
	6	Upper and lower left and right side recessed allen bolts
HTB265	5	Front brake disc torx mounting bolts
	1	Front of seat at the rear of the gas tank
HTB282	2	Large recessed 12-point brake caliper bolts (parts are modified for fitment)
	2	Large 12-point brake caliper to fork leg mounting bolts
	3	SILICONE over front and rear brake line to caliper mounting bolts as well as rear master cylinder banjo bolt
HTB288	12	SILICONE over rocker cover hex/torx bolts, requires a few drops of SILICONE on stem
HTB300	2	Right side lower transmission mounting bracket allen bolts (IMPORTANT: Install the 1-HTB311 on the lower engine to transmission mounting bolt prior to installing these HTB300s)
HTB311	5	On left side on engine case hex bolts under cylinder heads
	1	Left side shift lever hex bolt
	2	Front of frame support bracket bolt s above regulator
	1	SILICONE on brake master cylinder banjo fitting on the right side of handlebars
	2	Left & right side upper engine to transmission hex bolts
	1	Lower right side engine to transmission hex bolt (IMPORTANT: Install this 1-HTB311 on the lower engine to transmission mounting bolt prior to installing the 2-HTB300s)



INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTB342	1	Right front motor mount hex bolt
HTB343	1	Left side front motor mount hex nut
	1	Left side swing arm cover
HTB355	5	Left side over rear sprocket mounting hex bolts and washers
HTB365	5	Over rear brake disc torx mounting bolts
	1	SILICONE on the mounting torx bolt in the middle of the air cleaner cover
	1	SILICONE on the end of shifter lever
HTB420	6	SILICONE over left and right side front footboard torx mounting plate bolts
	8	SILICONE over torx bolts on rear fender struts
HTB500	2	On left side upper motor mount hex bolts above ignition
	2	Left and right side rear axle adjuster hex bolts
	1	Right side rear brake pedal mount at pivot
	1	Right side headlight mount hex bolt
	1	Left side front gas tank mount hex bolt
	1	Under the lower triple tree on the front fork hex bolt
	1	Front of frame support bracket bolt above regulator
	1	SILICONE over allen bolt on left side of transmission located right behind rear of shifter linkage
HTB600	1	Left side on headlight mount hex nut
	2	Right side exhaust support mount hex nuts underneath pipes below
	1	Exhaust stud next to rear passenger foot peg
HTB708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®
HTB733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTB999	1	Snap the slotted Hot Topper® over the left side axle hex nut and the Hot Topper® with the smooth inner wall on the right side axle rod

**Visit www.hottoppers.com
for up-to-date information!**

LIFETIME GUARANTEE
**IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!**
(WARRANTY EXCLUDES SERVICE WORK)