

HTBFDYWG2: COMPLETE TWIN CAM 2006-2008 DYNA WIDE GLIDE  
INCLUDES 119 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTB100	2	Regulator to frame mounting bolts
	2	Left side electrical panel cover
	2	Left side ignition coil cover
	1	Under triple tree at brake line junction
HTB181	4	Over small 12-point bolts on front and rear brake calipers
HTB200	1	Over bolt on rear shifter rod lever behind the inner primary cover
	4	On the upper handlebar clamp bolts ( <b>IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down</b> )
HTB220	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
HTB265	2	Fuel tank center console mounting bolts
	5	Front brake disc torq mounting bolts
	4	<b>SILICONE</b> over round torx bolts on both sides of upper and lower triple trees
	2	<b>SILICONE</b> on rear fork/axle adjuster bolts left and right side
	6	<b>SILICONE</b> on footpeg mounting bolts and rear footpeg mounting bracket bolts
	2	Rear belt guard mounting bolts
HTB282	4	<b>SILICONE</b> over left and right side extended footpeg mounting bracket torq bolts
	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear
HTB300	2	<b>SILICONE</b> on front and rear brake line to brake caliper mounting bolts
	4	<b>SILICONE</b> over inner front fender mounting nuts
HTB311	2	On lower front of frame isolator to front engine mount bracket bolts
	3	On exhaust support arm bolts behind transmission clutch release cover
HTB311	1	Left side over front gas tank mounting bolt
	1	Left side on shift lever bolt
	2	In front of the cylinders on the backside of the regulator to frame mounting nuts
	1	<b>SILICONE</b> on front master cylinder banjo fitting on right side of handlebars

HTB344	2	Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts
	1	Left side inner lower shock bolt
HTB355	5	Left side over rear sprocket mounting bolts and washers
HTB365	5	Over rear brake disc mounting bolts
	1	<b>SILICONE</b> on the mounting bolt in the middle of the air cleaner cover
HTB420	4	<b>SILICONE</b> over torx bolts on rear fender struts
HTB500	1	Bottom side of lower triple tree mounting bolt
	1	Headlight mounting bolt
	2	On left side upper motor mount bolts above horn under gas tank
HTB600	1	Headlight mounting nut
	4	Over footpeg mounting nuts
	3	Right side over exhaust pipe nuts and studs ( <b>SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE</b> )
HTB708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTB733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® ( <b>IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen</b> )
HTB777	1	Snap black sleeve into chrome Hot Topper®, then slide the slotted sleeve over the left side hex axle nut and the Hot Topper® without the sleeve on the right side axle rod
<b>OR</b>		
HTB999	1	(2008) Push the HTB997 on the left side axle rod and the HTB998 on the right side hex nut

#### **ADDITIONAL OPTIONS NOT INCLUDED**

HTB342	2	<b>SILICONE</b> over top shock bolts
HTB365	2	<b>SILICONE</b> over top and bottom shock bolts
HTB560	1	Windshield screw cover kit that fits all Harley Davidson® detachable lexan windshields (9-HTB555)