



# INSTRUCTIONS

## THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 220 PIECES

**Kit Number**  
HTBFL9

**Model Fitment**  
ALL 2008-UP FLH/FLT MODELS

**NOTE**

**Additional installation help available worldwide:  
info@hottoppers.com or talk to a live USA based tech  
toll free 877-446-8867 (USA only)**

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTB100. As you install them note the size and style of the other zinc original uncovered fasteners.

**\*\* You might have a few extra pieces left over depending on the model you ride! \*\***

PART #	QTY	LOCATION OF PART
HTB100	13	Left side primary cover allen bolts
	1	Left side crankshaft position sensor allen bolt in front of cylinders next to oil filter
	6	Right side top of transmission housing cover allen bolts
	6	Right side clutch release cover allen bolts
	10	Right side cam cover allen bolts right side
	8	Right side lifter cover push rod allen bolts right side
	2	Front of bottom saddlebag support arms bolt underneath the saddlebag
	2	Allen bolts on black bracket in front of gas tank above front cylinder <b>(Only on 08 Ultra Classic® Electra Glide®)</b>
	HTB200	1
1		Over allen bolt on rear shifter rod lever behind the inner primary cover
8		Right side transmission housing allens bolts
1		Front safety bar mounting allen bolt to frame
2		Right side starter housing mounting bolts behind upper transmission cover
2		Right side brake master cylinder
HTB211	2	Left and right side upper rear saddlebag mounting bracket hex bolts
	2	Front of bottom saddlebag support arms hex nut underneath the saddlebag
	7	Hex nuts underneath tour pack <b>(Only for Ultra Classic® Electra Glide® - Only 6 on 09 models)</b>
HTB220	2	Front of engine over recessed allen bolts at oil filter mount
	4	Snip stems and <b>SILICONE</b> over the recessed allen bolts on Brembo brake calipers
HTB265	2	On both inner fairing lowers screws that clamps the lowers to the engine guard <b>(Only for Ultra Classic® Electra Glide®)</b>
	4	Left and right side front of saddlebag guard mounts <b>(Only for Ultra Classic® Electra Glide®)</b>
	4	<b>SILICONE</b> over recessed torx bolts on Left and right side fairing support bracket bolts on sides of passing lamp bracket <b>(Only for FLHX Street Glide®)</b>
	4	Left and right side on the top saddlebag support bracket smooth sided torx mount bolts
HTB282	4	Large 12-point bolts that mount front brake calipers to fork legs
HTB288	8	<b>SILICONE</b> over rocker cover hex/torx bolts, requires a few drops of <b>SILICONE</b> on stem



# INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTB300	2	Left side lower front stabilizer arm allen mounting bolt <b>(Only on 08 models)</b>
	2	Motor mount bolt on top front on front cylinder <b>(Only 1 on 08 models)</b>
	1	<b>SILICONE</b> over exhaust bracket hex nut behind rear cylinder above starter <b>(Only on 08 models)</b>
	2	Right side over the hex nuts on the bottom of fork leg at the front axle
	2	Left and right side rear footboard mounting allen bolts
	4	<b>SILICONE</b> over left side kickstand mounting plate & footboard mounting allen bolts <b>(Only on 09-UP models)</b>
HTB311	5	<b>SILICONE</b> over right side front footboard mounting plate allen bolts <b>(Only on 09-UP models)</b>
	5	On left side over engine case hex bolts under cylinders
	3	Left side kickstand mounting plate hex bolts/nuts <b>(Only on 08 models)</b>
	2	Over front gas tank mounting hex bolts left and right side <b>(Only on 08 Models)</b>
	2	Both sides fork tube drain plug
HTB365	2	<b>SILICONE</b> over banjo fittings on brake master cylinders (handlebar and behind brake pedal)
	1	Left side on side stand mounting hex bolt
	3	Left and right side upper and lower engine to transmission hex bolts
	4	Left and right side footboard mounting plate hex bolts near swing arm <b>(Only 2 on left side on 09-UP models)</b>
HTB400	1	<b>SILICONE</b> on the mounting allen bolt in the middle of the air cleaner cover
	2	<b>SILICONE</b> over ends of heel/toe shift lever pegs
	1	<b>SILICONE</b> over recessed allen in the middle of the right front floorboard bracket
HTB420	2	Left and right side bottom engine guard <b>SILICONE</b> over mounting bolts
	1	<b>SILICONE</b> over the large hex nut on the right side rear brake pedal mount at pivot under the front floorboard
HTB500	2	Backside of left and right side lower triple tree <b>(Only on 09-UP models)</b>
	10	Front brake rotor button torx mounting bolts <b>(Order 4 more for 2011-UP Screamin Eagle)</b>
	3	Left front lower engine mount hex bolt <b>(Only on 08 models)</b>
	3	Motor mount bolts on top of front cylinder <b>(Only 2 on 09-UP models)</b>
	2	Left side upper motor mount hex bolts above horn under gas tank
	4	Left and right side on smooth sided torx bolts facing rear of bike connecting the saddlebag support bars to the support brackets <b>(Only 2 on 09 models)</b>
	1	<b>SILICONE</b> over black allen bolt behind inner primary where shifter linkage connects
	2	Left and right side on smooth sided torx bolts on lower rear fender saddlebag support brackets * Bracket mounted onto side of rear fender behind saddlebag <b>(Only on 08 models)</b>
HTB555	4	Left and right side fairing support bracket torx bolts on sides of passing lamp bracket <b>(Not on FLHX Street Glide®)</b>
	4	Left and right side on the top saddlebag support bracket smooth sided torx mount bolts <b>(Only on 08 models)</b>
	1	<b>SILICONE</b> over right side hex nut toward rear of transmission cover behind exhaust
	3	<b>SILICONE</b> on backside of left and right side lower triple tree, top of shocks (small hex bolts) <b>(1 extra on right side on 09-UP Ultra Classic® Electra Glide®)</b>
HTB600	2	Front bottom of inner frame hex nuts (behind lower crash bar mounting bolts)
	2	Left front lower engine mount hex bolts <b>(Only on 09-UP models)</b>
	4	Left and right side on smooth sided torx bolts on lower rear fender saddlebag support brackets Bracket mounted onto side of rear fender behind saddlebag <b>(Only on 09 models)</b>
HTB708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®
HTB733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® <b>(IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)</b>
HTB999	1	Snap the slotted Hot Topper® over the left side axle hex nut and the Hot Topper® with the smooth inner wall on the right side axle rod

**Visit [www.hottoppers.com](http://www.hottoppers.com)  
for up-to-date information!**

**LIFETIME GUARANTEE  
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,  
OR DISCOLORS WE REPLACE IT FREE!  
(WARRANTY EXCLUDES SERVICE WORK)**