



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 171 PIECES

Kit Number
HTBROC

Model Fitment
2008-UP SOFTAIL® ROCKER MODELS

NOTE

**Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)**

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTB100	13	Around the primary cover allen bolts
	6	Over transmission clutch release cover allen bolts
	10	Right side cam cover allen bolts
	8	Right side Lifter cover push rod allen bolts
	6	Right side upper transmission housing cover allen bolts
	2	Front of frame regulator mounting allen bolts
	2	On front of regulator recessed allen bolts
	1	Over top dash board mounting allen bolt with silicone
	1	Crankshaft position sensor allen bolt in front of cylinders next to oil filter
	HTB200	1
8		Right side transmission housing allen bolts
HTB211	1	Over license plate mounting nut
HTB220	3	Mount in three threaded holes on the back side of front brake caliper- snip half the stem off one of them for flush fitment in top front hole.
	2	Front of engine on oil filter mount
	2	Silicone over left and right side lower triple tree recessed allen fork leg pinch bolts
HTB265	5	Front brake disc torx mounting bolts
	4	Use a small dab of silicone to mount over the two recessed allen bolts holding rear left and right side fender struts to frame under the seat
HTB282	6	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 2 on the rear
HTB288	8	SILICONE over rocker cover hex/torx bolts, requires a few drops of SILICONE on stem
HTB300	2	Found under seat on top of left and right side frame tubes
	2	Right side lower transmission mounting bracket allen bolts (IMPORTANT: Install the 1-HTD311 on the lower engine to transmission mounting bolt prior to installing these HTD300s)
	1	Left side behind inner primary below upper transmission allen bolt
	4	On the handlebar clamp allen bolts



INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTB311	5	On left side on engine case hex bolts under cylinder heads
	1	Left side shift lever hex bolt
	1	SILICONE on brake master cylinder banjo fitting on the right side of handlebars
	2	Left & right side upper engine to transmission hex bolts
	1	Lower right side engine to transmission hex bolt (IMPORTANT: Install this 1-HTD311 on the lower engine to transmission mounting bolt prior to installing the 2-HTD300s)
	1	over horn mounting bolt on the front frame downtube
	4	silicone over inner front fender mounting bolts on fork legs
	HTB342	2
HTB343	3	Left side upper and lower front motor mount hex nut & left side swing arm nut rear of primary cover
HTB344	3	Under the top triple tree over 2 handlebar riser bolts and one on right side rear shock bolt under transmission
HTB355	5	Left side over rear sprocket mounting hex bolts and washers
HTB365	5	Over rear brake disc torx mounting bolts
	1	SILICONE on the mounting torx bolt in the middle of the air cleaner cover
HTB420	6	SILICONE over left and right side front footboard torx mounting plate bolts
HTB500	2	On left side upper motor mount hex bolts above horn under gas tank
	2	Left and right side rear axle adjuster hex bolts
	1	Right side rear brake pedal mount at pivot
	1	Right side headlight mount hex bolt
	1	Left side front gas tank mount hex bolt
	2	Right side over two hex bolts on muffler support to frame
HTB555	3	Front & rear brake line to caliper banjo bolts as well as one on rear master cylinder banjo bolt
HTB600	2	Left side – silicone over belt guard acorn bolts to match pulley bolt covers
	1	Right side exhaust support mount hex nut between exhaust pipes
HTB708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®
HTB733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Change one bolt at a time to prevent fluid leak due to gasket disturbance)

LIFETIME GUARANTEE
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!
(WARRANTY EXCLUDES SERVICE WORK)

**Visit www.hottoppers.com
for up-to-date information!**