

HTBSPC: COMPLETE 2004-UP SPORTSTER® KIT  
INCLUDES 187 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTB100	16	Around the primary cover
	1	Front left side on the crankshaft position sensor
	1	Speed sensor bolt behind the starter housing
	1	Brake line junction mounting bolt under triple tree
	8	On the top of rocker box covers
	8	Right side lifter cover push rod bolts
	4	Right side on the front of the lifter covers
	4	<b>SILICONE</b> the Hot Toppers® onto the 6mm mounting screws on the handlebar brake and clutch housings
	13	Right side gear case cover
	1	Right side underneath gear case cover
HTB200	2	Bolts on the top of upper triple tree
	4	On the handlebar clamp bolts ( <b>IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down</b> )
	1	On the right side gas tank mounting bolt
	1	Left side behind filler cap
	2	Rear brake master cylinder and reservoir assembly mounting bolts underneath the middle of the bike
	1	Right side rear belt guard mounting bolt
	1	<b>SILICONE</b> on the left side top of the shifter arm bracket
	1	<b>SILICONE</b> over recessed allen bolt on front of oil filter mount
HTB211	1	Behind the primary cover on the grounding bolt behind the starter housing
HTB220	2	On the top of the forward control footpeg mounting bolts
	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
	2	<b>SILICONE</b> over the bolt on upper bracket of steering head bracket assembly ( <b>NOTE: Snip the stem off of the part for the left side</b> )
	1	Cut off ½ of the stem and then <b>SILICONE</b> over the threaded case hole on the front brake caliper ( <b>NOTE: Order 1 more piece if your bike has dual disc</b> )
HTB265	2	Frame to brake master cylinder and reservoir assembly mounting bolts behind the primary cover under the left side rear footpeg

	2	Air cleaner mounting bolts
	4	Bolts on both sides of the rear fender struts
	2	Left side on the shifter rod bolts ( <b>Forward controls only</b> )
	5	Front brake disc mounting bolts ( <b>IMPORTANT: Install one Hot Topper® and rotate tire one complete rotation, make sure the Hot Topper® clears the fork leg</b> ) ( <b>NOTE: Order 5 more pieces if your bike has dual disc</b> )
	2	Left side behind the reservoir assembly for the rear brake master cylinder ( <b>NOTE: The bolt above the cap is friction fit but the one below needs SILICONE</b> )
	2	<b>SILICONE</b> over the front lower left side engine to frame mounting bolts
	1	<b>SILICONE</b> in the center of the choke knob
	1	<b>SILICONE</b> on the front of the lower right side fork pinch bolt
	4	<b>SILICONE</b> on the bolts on the sides of the upper and lower triple trees
HTB282	2	On the front brake caliper to fork leg mounting bolts ( <b>NOTE: Order 2 more pieces if your bike has dual disc</b> )
HTB300	2	On the top motor mount bolts left side behind horn
	1	Right side exhaust to gear case mounting bolt
	1	Right side front exhaust bracket bolt under the gear case
	1	Right side exhaust mounting bracket bolt behind the gear case
	2	<b>SILICONE</b> over upper front cylinder tie-link bracket to frame bottom side engine mounting nuts
	1	<b>SILICONE</b> over lower front cylinder tie-link bracket to frame bottom side engine mounting nut
HTB311	4	On the inner front fender mounting nuts
	5	On the left side engine case bolts
	2	On the backside of the regulator to frame black mounting bolts
	4	Right side on the underside of the exhaust bracket mounting bolts
	1	Left side <b>SILICONE</b> on the black rubber boot on the front brake caliper
	4	<b>SILICONE</b> on the brake line banjo bolts on both front and rear calipers as well as upper brake master cylinder on the top of handlebars and below left side passenger peg on brake master cylinder
HTB342	1	Over the top of the fork stem bolt
HTB344	2	Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts
HTB355	5	Left side over rear sprocket mounting bolts and washers
	1	Front lower left side motor mount bolt, cut out the inside walls of the part and <b>SILICONE</b> it over the bolt
HTB365	1	Left side on the back of the primary cover lower frame to engine mounting bolt
	4	Upper front cylinder tie-link bracket to frame engine mounting bolts
	4	Lower front cylinder tie-link bracket to frame engine mounting bolts
	5	Over rear brake disc mounting bolts
	2	<b>SILICONE</b> over the upper mounting bolts on the top of the rear shock
HTB420	1	Left side on the underside of the primary cover
	2	Front of front cylinder tie-link bracket mounting bolts
HTB500	1	Right side headlight mounting bolt
	1	<b>SILICONE</b> on the left side rear brake caliper black mounting pin bolt ( <b>NOTE: Order 1 more piece if your bike has dual disc</b> )

HTB555	2	<b>SILICONE</b> on the front of the regulator mounting bolts
HTB600	1	Right side back of lower fork leg pinch bolt
	1	Left side headlight mounting bolt
	2	<b>SILICONE</b> over exhaust nuts on right side ( <b>SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement</b> )
HTB732	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® ( <b>IMPORTANT: When replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen</b> )
HTB777	1	(2004-2007) Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over left side hex axle nut and the smooth sleeve over right side smooth axle rod
		<b>OR</b>
HTB999	1	(2008-UP) Push the HTB997 on the left side axle rod and the HTB998 on the right side hex nut

#### **ADDITIONAL OPTIONS NOT INCLUDED**

HTB100	1	<b>SILICONE</b> over brake line clamp mounting bolt on right side of upper triple tree
HTB220	8	<b>SILICONE</b> over all of the footpeg mounting bracket bolts
HTB311	3	Lower engine case bolts beneath the primary cover
	1	Left side gas tank mount cut excess thread off bolt and then cover nut and stud
HTB355	2	Cut insides of part out and then <b>SILICONE</b> over left and right side rear fork (swing arm) bolt
HTB555	1	Electrical bracket mounting bolt on the right side underneath the seat
	3	Right side <b>SILICONE</b> over lower belt guard mounting bolts
HTB600	2	Lower front engine mounting nuts and studs, cut out ½ of the wall and then <b>SILICONE</b> over nuts underneath the regulator

REV. 09/12/06