



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 155 PIECES

Kit Number
HTBV-ROD7

Model Fitment
2007-UP ALL V-ROD MODELS

NOTE

Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

The V-ROD features metric fasteners. All of the Hot Toppers® in this kit REQUIRE SILICONE!

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTB100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTB100	1	Under lower triple tree NO SILICONE REQUIRED
	2	Right side on starter motor body screws
	2	Right side by thermostat housing (1), Front of rear cylinder (1)
	4	Replace button T-25 torq bolts in clutch and brake lever perch bolts with supplied 1/4 x 20 x 1 allen bolts. Push on Hot Toppers®
	4	Replace torq bolts in front fender that hold chrome cover on with 1/4 x 20 x 1/2 allen bolts and 3/16 nuts. Push on Hot Toppers®
HTB200	12	Rocker box bolts
	14	Primary cover
	2	On left (1) & right (1) side louvered plates at steering stem
	13	Cam cover
	3	Clutch cover
	2	Starter motor mount bolts
	7	Right side on water pump cover
	2	Right side on top of thermostat housing
	2	Above rear shifter linkage arm
	1	Left side above engine oil drain
HTB211	2	Left (1) and right (1) backside of radiator to mounting bracket bolts
HTB220	4	Snip stems and mount in recessed allens in front fender support bolts on left & right side front forks
	2	Snip stems and mount in derby cover
	4	Left (2) & right (2) side, Snip stems and mount in front brake calipers
HTB265	4	Mount on upper and lower left (2) and right (2) side of triple tree
	10	Left (5) & right (5) side mount on torq bolts on front brake rotor
	5	Mount on torq bolts on rear brake rotor
	4	Left (2) & right (2) side footpeg to frame mounting bracket bolts



INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTB282	4	Left (2) & right (2) side on front brake caliper 12 pt. mounting bolts NO SILICONE REQUIRED
HTB311	2	Brake pedal master cylinder bolt (1), Rear caliper banjo bolt (1)
	2	Left (1) & right (1) side on master cylinder banjo bolts on handlebars
	2	Right side below swingarm, mounting bracket bolts from frame to pipes
	1	Right side rear foot peg mounting bracket nut
HTB365	4	Mount on top and bottom left and right side rear shock mounting bolts
HTB420	1	Right side above rear swingarm bolt
	2	Left side behind horn, top of left & right side cylinders
	4	Left (2) & right (2) side front of frame tubes
	1	Front headlight mounting bolt (backside stud sticks out to far from nut to cover)
	2	Linkage rod mounting bolts in front of starter
	4	Left (2) & right (2) side bottom middle of frame mounting bolts
	1	Right side bottom of front cylinder
	2	Right side rear brake caliper mounting bolts
1	Right side rear foot peg mounting bracket nut	
HTB500	2	Center of bike behind rear cylinder engine case bolts
HTB770	1	Right side front axle (no sleeve) NO SILICONE REQUIRED
	1	Left side front axle (no sleeve)

**Visit www.hottoppers.com
for up-to-date information!**

LIFETIME GUARANTEE
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!
(WARRANTY EXCLUDES SERVICE WORK)