

HTDDYWG2: COMPLETE TWIN CAM 2006-2008 DYNA WIDE GLIDE KIT
INCLUDES 195 PIECES

HOT TOPPERS® are manufactured to fit American Standard fasteners.

There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email info@hottoppers.com or call our toll free USA number 877-446-8867 with any questions or comments.

HTD100	2	Regulator to frame mounting bolts
	13	Around the primary cover
	1	Crankshaft position sensor bolt in front of cylinders next to oil filter
	6	Right side clutch release cover
	1	Right side in front of clutch release cover on oil dip-stick housing
	6	On upper transmission housing cover bolts
	10	Cam cover bolts right side
	8	Lifter cover push rod bolts right side
	2	Left side electrical panel cover
	2	Left side ignition coil cover
	1	Under triple tree at brake line junction
1	Beneath starter, speed sensor mounting bolt	
HTD181	4	Over small 12-point bolts on front and rear brake calipers
HTD200	1	Over bolt on rear shifter rod lever behind the inner primary cover
	6	Right side around transmission clutch release cover on transmission housing
	4	On the upper handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
	1	Left side inner primary cover to engine case mounting bolt (below ignition coil)
HTD220	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
HTD265	2	Fuel tank center console mounting bolts
	5	Front brake disc torq mounting bolts
	4	SILICONE over round torx bolts on both sides of upper and lower triple trees
	2	SILICONE on rear fork/axle adjuster bolts left and right side
	6	SILICONE on footpeg mounting bolts and rear footpeg mounting bracket bolts
	2	Rear belt guard mounting bolts
	4	SILICONE over left and right side extended footpeg mounting bracket torq bolts
HTD282	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear

	2	SILICONE on front and rear brake line to brake caliper mounting bolts
HTD288	8	SILICONE on rocker cover bolts, requires a few drops of SILICONE on stem
HTD300	4	SILICONE over inner front fender mounting nuts
	2	On lower front of frame isolator to front engine mount bracket bolts
HTD311	6	On left side on engine case bolts under cylinder heads
	3	On exhaust support arm bolts behind transmission clutch release cover
	1	Left side over front gas tank mounting bolt
	1	Left side on shift lever bolt
	2	In front of the cylinders on the backside of the regulator to frame mounting nuts
	1	SILICONE on front master cylinder banjo fitting on right side of handlebars
	3	Both sides upper and right side lower engine to transmission bolts (2007 models) (2006 models need 3-HTD600)
HTD344	2	Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts
	1	Left side inner lower shock bolt
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	1	SILICONE on the mounting bolt in the middle of the air cleaner cover
HTD420	4	SILICONE over torx bolts on rear fender struts
HTD500	1	Bottom side of lower triple tree mounting bolt
	1	Headlight mounting bolt
	2	On left side upper motor mount bolts above horn under gas tank
	4	Lower front motor mount bolts on front engine mount bracket
HTD600	1	Headlight mounting nut
	4	Over footpeg mounting nuts
	2	Left side of lower front motor mount nuts
	3	Right side over exhaust pipe nuts and studs (SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE)
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTD777	1	(2006-2007) Snap black sleeve into chrome Hot Topper®, then slide the slotted sleeve over the left side hex axle nut and the Hot Topper® without the sleeve on the right side axle rod
OR		
HTD999	1	(2008) Push the HTD997 on the left side axle rod and the HTD998 on the right side hex nut

ADDITIONAL OPTIONS NOT INCLUDED

HTD342	2	SILICONE over top shock bolts
HTD365	2	SILICONE over top and bottom shock bolts
HTD560	1	Windshield screw cover kit that fits all Harley Davidson® detachable lexan windshields (9-HTD555)