



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 161 PIECES

Kit Number
HTDMUSCLE

Model Fitment
2008-UP V-ROD MUSCLE

NOTE

Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

The V-ROD features metric fasteners. All of the Hot Toppers® in this kit REQUIRE SILICONE!

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

| PART # | QTY | LOCATION OF PART |
|--------|-----|---|
| HTD100 | 1 | Under lower triple tree NO SILICONE REQUIRED |
| | 2 | Right side on starter motor body screws |
| | 2 | Right side by thermostat housing (1), Front of rear cylinder (1) |
| | 4 | Replace button T-25 torq bolts in clutch and brake lever perch bolts with supplied ¼ x 20 x 1 allen bolts. Push on Hot Toppers® |
| BOLTS | 4 | ¼ x 20 x 1 allen bolts |
| HTD200 | 12 | Rocker box bolts |
| | 14 | Primary cover |
| | 13 | Cam cover |
| | 3 | Clutch cover |
| | 2 | Starter motor mount bolts |
| | 7 | Right side on water pump cover |
| | 2 | Right side on top of thermostat housing |
| | 2 | Above rear shifter linkage arm |
| | 1 | Left side above engine oil drain |
| | 2 | Bottom Left (1) & right (1) side front fork to brake caliper 12 pt. mounting bolts |
| HTD211 | 2 | Left (1) and right (1) backside of radiator to mounting bracket bolts |
| HTD220 | 2 | Recessed allen bolts on rear brake caliper (snip stem off of parts) |
| | 4 | Recessed allen bolts on front brake calipers (snip stem off of parts) |
| | 4 | Recessed allen bolts mounting front fender to fork legs (snip stem off of parts) |
| | 2 | Upper triple tree (above headlight) (snip stem off of parts) |
| | 1 | Recessed allen steering stem pinch bolt |
| HTD265 | 4 | Mount on upper and lower left (2) and right (2) side of triple trees |
| | 10 | Left (5) & right (5) side front rotor torq bolts |
| HTD282 | 2 | Top Left (1) & right (1) side front fork to brake caliper 12 pt. mounting bolts NO SILICONE REQUIRED |



INSTRUCTIONS

| PART # | QTY | LOCATION OF PART |
|--------|-----|--|
| HTD311 | 2 | Brake pedal master cylinder bolt (1), Rear caliper banjo bolt (1) |
| | 2 | Left (1) & right (1) side on master cylinder banjo bolts on handlebars |
| | 3 | Right side below swingarm, mounting bracket bolts from frame to pipes |
| HTD365 | 4 | Mount on top and bottom left and right side rear shock mounting bolts |
| | 5 | Rear rotor torq bolts |
| HTD400 | 1 | Upper engine to frame (top front of front cylinder) motor mount nut |
| HTD420 | 1 | Right side above rear swingarm bolt |
| | 2 | Left side behind horn, top of left & right side cylinders |
| | 4 | Left (2) & right (2) side front of frame tubes |
| | 4 | Left (2) & right (2) side bottom middle of frame mounting bolts |
| | 1 | Right side rear brake caliper allen mounting bolt |
| | 6 | Upper engine to frame (top front of front cylinder) motor mount bolts |
| HTD500 | 2 | Center of bike behind rear cylinder engine case bolts |
| HTD555 | 4 | Button head mounting bolts on front fender |
| | 10 | Upper front top of frame louver plate mounting bolts |
| HTD810 | 2 | Left (1) & right (1) side swingarm bolts |
| HTD820 | 4 | Left side indentations in cylinder heads |
| HTD997 | 1 | Right side front axle NO SILICONE REQUIRED |
| HTD998 | 1 | Left side front axle NO SILICONE REQUIRED |

**Visit www.hottoppers.com
for up-to-date information!**

LIFETIME GUARANTEE
IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!
(WARRANTY EXCLUDES SERVICE WORK)