



INSTRUCTIONS

THE GENUINE USA MADE HOT TOPPERS® BIKE KIT 176 PIECES

Kit Number
HTDXBONES

Model Fitment
2008-UP SOFTAIL® CROSS BONES™ MODEL

NOTE

Additional installation help available worldwide:
info@hottoppers.com or talk to a live USA based tech
toll free 877-446-8867 (USA only)

HOT TOPPERS® are manufactured in the USA to fit American Standard fasteners. There are some rare occasions where even though the nut or bolt is an American Standard fastener, the Hot Topper® may not achieve a friction fit. In that case simply install a drop of silicone on the inside wall of the Hot Topper® using Napa® part number 765-1481 clear silicone or facsimile.

Please DO NOT USE adhesive products to mount HOT TOPPERS®. The Napa® product we recommend will allow for an easier removal when service is required. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up so don't over fill our part. A little dab goes a long way.

Before you begin this easy installation process we suggest you completely wash and dry your motorcycle, especially the fasteners to be covered.

Note the accompanying diagram that calls out the part number of each Hot Topper® mounted on the adhesive patch. Start the install process with the smallest HOT TOPPER® - the HTD100. As you install them note the size and style of the other zinc original uncovered fasteners.

PART #	QTY	LOCATION OF PART
HTD100	13	Around the primary cover allen bolts
	6	Over transmission clutch release cover allen bolts
	10	Right side cam cover allen bolts
	8	Right side Lifter cover push rod allen bolts
	6	Top of transmission housing cover allen bolts
	2	Front of frame regulator mounting allen bolts
	2	On front of regulator recessed allen bolts
	1	Brake line junction mounting allen bolt under triple tree
	1	Speed sensor allen bolt on top of transmission housing
	1	Crankshaft position sensor allen bolt in front of cylinders next to oil filter
	1	Right side over allen bolt on frame down tube above transmission behind engine
	4	Left and right side front floorboard mounting brackets
	1	Right side of frame downtube above the top of transmission
	HTD200	1
8		Right side surrounding transmission housing allen bolts
1		Left side over shift lever allen add a drop of silicone because head of bolt is short
HTD211	4	Over nuts on left and right side front floorboard mounting brackets
HTD220	1	Silicone in recessed allen bolt below headlight on headlight mount
	2	Front of engine on oil filter mount
	4	On the handlebar clamp recessed allen bolts
	2	SILICONE in recessed holes on left and right side of the top triple tree pinch bolt at steering stem bolt
	1	Snip stem on 220 and SILICONE over recessed allen in left side brake caliper mounting plate
HTD265	5	Front brake disc torx mounting bolts (NOTE: order 5 more of you bike has dual front discs)
HTD288	8	SILICONE over rocker cover hex/torx bolts, requires a few drops of SILICONE on stem



INSTRUCTIONS

PART #	QTY	LOCATION OF PART
HTD300	3	Left side top and bottom front shock mount and headlight mount
	1	Right side exhaust support between exhaust pipes
	2	Right side lower transmission mounting bracket allen bolts (IMPORTANT: Install the 1-HTD311 on the lower engine to transmission mounting bolt prior to installing these HTD300s)
	1	Front brake caliper support plate
HTD311	5	On left side on engine case hex bolts under cylinder heads
	1	SILICONE on brake master cylinder banjo fitting on the right side of handlebars
	2	Left & right side upper engine to transmission hex bolts
	1	Lower right side engine to transmission hex bolt (IMPORTANT: Install this 1-HTD311 on the lower engine to transmission mounting bolt prior to installing the 2-HTD300s)
HTD342	1	Right front motor mount hex bolt
HTD343	1	Left side front motor mount hex nut
HTD344	2	Mount over hex bolts with cut side down on left and right side lower
HTD355	5	Left side over rear sprocket mounting hex bolts and washers
HTD365	5	Over rear brake disc torx mounting bolts
	1	SILICONE on the mounting torx bolt in the middle of the air cleaner cover
HTD420	6	SILICONE over left and right side front footboard torx mounting plate bolts
	10	SILICONE over torx bolts on rear fender struts
HTD500	2	On left side upper motor mount hex bolts above horn under gas tank
	1	Left and right side rear axle adjuster hex bolts
	1	Right side rear brake pedal mount at pivot
	2	Right side exhaust support nuts on frame below exhaust pipes
HTD555	3	Front & rear brake line to caliper mounting bolts as well as rear master cylinder banjo bolt
HTD600	1	SILICONE over black post on the front brake caliper
	1	Right side exhaust support mount hex nut on threaded studs between pipes
	2	SILICONE over rear brake caliper mounting bolts
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch lever perches with supplied allen bolts and press on Hot Toppers®
HTD733	1	Conversion kit!! Replace button torx screws on derby cover with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTD998	2	Over front left and right side axles
	2	Left and right side swing arm bolts
HTD820	1	Mount with silicone in recessed area on front brake caliper

LIFETIME GUARANTEE

IF A HOT TOPPER® FALLS OFF, CHIPS, PEELS,
OR DISCOLORS WE REPLACE IT FREE!
(WARRANTY EXCLUDES SERVICE WORK)

Visit www.hottoppers.com
for up-to-date information!