

FDYWG: FINISHING KIT FOR TWIN CAM DYNA WIDE GLIDE® KIT  
INCLUDES 154 PIECES

**HOT TOPPERS® are manufactured to fit American Standard fasteners.**

**There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email [info@hottoppers.com](mailto:info@hottoppers.com) or call our toll free USA number 877-446-8867 with any questions or comments.**

HTD100	4	left side electrical panel cover
	1	Under triple tree at brake line junction
	2	Regulator mount ( <b>NOTE: 2004-up</b> )
	2	On left side ignition coil cover
HTD181	4	Over small 12-point bolts on front and rear brake calipers
HTD200	1	Over shifter rod lever mounting bolt behind the inner primary cover
	2	Right side starter housing mounting bolts behind upper transmission cover
	4	On the upper handlebar clamp bolts ( <b>IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down</b> )
	2	<b>SILICONE</b> on front and rear brake line to brake caliper mounting bolts
HTD211	2	Regulator assembly to frame mounting nuts ( <b>NOTE: PRE-2004</b> )
	1	On the middle oil filter mounting kit bolt
	2	Backside of ignition coil bracket enter from right side cover nuts and studs ( <b>NOTE: PRE-2004</b> )
HTD220	4	In recessed allen bolts on both sides of front fork leg sliders that support front Fender
	2	Remove screws from left and right side of top triple tree, <b>SILICONE</b> in empty holes
HTD265	5	Front brake disc mounting bolts
	1	Over oil hose cover bolt right side of transmission
	2	Instrument panel mounting bolts ( <b>NOTE: 2004-up</b> )
	1	<b>SILICONE</b> in the center of the choke knob ( <b>Carbureted models only</b> )
HTD282	7	Large 12-point bolts on both front and rear brake calipers, 4 on the front and 3 on the rear
HTD300	2	On rear fork/axle adjuster bolts left and right side
	1	Left side under primary cover rear footpeg to frame mounting bolt
	2	Left side rear footpeg mounting bolts
	2	On the right side over the nuts on the bottom of fork leg at the front axle
	1	<b>SILICONE</b> over hex nut behind electronics box mount ( <b>NOTE: PRE-2004</b> )

HTD311	4	On the inner front fender, change acorns to ½” nuts, push on Hot Toppers®
	3	On exhaust support arm bolts behind transmission clutch release cover
	2	Right side below ignition switch over black bolts
	1	Over front gas tank mounting bolt left side
	1	Replace acorn on left side shifter rod with supplied ½” nut and push on Hot Topper®
	2	Over rear belt guard mounting bolts
	2	In front of the cylinders on the backside of the regulator to frame mounting nuts
	1	Left side gas tank mounting bolt
	2	Both sides fork tube drain plug
	1	<b>SILICONE</b> on front master cylinder banjo fitting on right side of handlebars
	HTD344	2
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	1	<b>SILICONE</b> on the mounting bolt in the middle of the air cleaner cover
	4	<b>SILICONE</b> on left and right side forward control mounting bolts
HTD420	1	Right side rear footpeg mount
	5	Left side over rear sprocket mounting bolts
	2	Lower triple tree pinch bolts
	4	<b>SILICONE</b> over torx bolts on rear fender struts
HTD500	4	Over each footpeg mounting bolt
	1	Right side headlight mount
	1	Under lower triple tree on front fork
HTD600	4	Over all footpeg mounting nuts
	1	Left side headlight mount
	3	Right side over exhaust pipe nuts and studs ( <b>SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE</b> )
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with Supplied allen bolts and press on Hot Toppers®
HTD723	1	Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® ( <b>IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen</b> )
HTD777	1	Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over the left side hex axle nut and the smooth sleeve on the right side smooth axle rod

#### ADDITIONAL OPTIONS NOT INCLUDED

HTD100	1	<b>SILICONE</b> on brake line clamp on the backside upper triple tree
	2	<b>SILICONE</b> above the air cleaner on the top carburetor screws
HTD200	1	<b>SILICONE</b> on right side rear brake line master cylinder banjo bolt below rear footpeg behind exhaust pipe
	1	<b>SILICONE</b> over regulator electrical line bracket mounting nut under oil filter

HTD300	4	<b>SILICONE</b> on the right side exhaust to frame mounting nuts and bolts
HTD555	2	<b>SILICONE</b> on the left side of the bottom debris deflector on underside of rear fork mounting bolts
	13	Windshield screw covers that fits all Harley Davidson® detachable lexan windshields 9 on the front and 4 on the sides
HTD600	1	<b>SILICONE</b> over acorn nut on horn cover
HTD820	1	<b>SILICONE</b> on engine oil filler cap