

FRK: FINISHING KIT FOR TWIN CAM ROADKING®/ROADKING® CLASSIC KIT
INCLUDES 125 PIECES

HOT TOPPERS® are manufactured to fit American Standard fasteners.

There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email info@hottoppers.com or call our toll free USA number 877-446-8867 with any questions or comments.

HTD100	1	Left side in front of shift lever right in front of engine
	1	Crankshaft position sensor bolt in front of cylinders on left side next to oil filter
	2	Front of bottom saddlebag support arms bolt underneath the saddlebag
	4	Right side behind clutch release cover on the oil filler spout
HTD181	4	Over small 12-point bolts on front brake calipers
HTD200	1	Top screw on engine guard behind front fender
	1	SILICONE on left side bolt on top of shifter
	4	SILICONE on left and right side front brake line to brake caliper mounting bolts, rear master cylinder banjo bolt in front of right side footboard, and front master cylinder banjo fitting on right side of handlebars
HTD211	2	Regulator assembly to frame mounting nuts
	4	Left and right side front and rear saddlebag mounting bracket bolts
	2	Front of bottom saddlebag support arms mounting nut underneath the saddlebag
	1	On the middle oil filter mounting kit bolt
	1	SILICONE on right side exhaust clamp mounting bolt, middle of bike
HTD220	1	Snip off stem of mushroom cap, file it evenly down, and SILICONE it over the casing hole in front of the clutch release cover on transmission housing
HTD265	10	Front brake disc mounting bolts
	1	Right side in front of clutch release cover on middle mounting bolt for oil hose cover
	1	Under the lower triple tree above front fender
	1	SILICONE in the center of the choke knob (Only on carbureted models)
HTD282	8	Large 12-point bolts on front brake calipers
HTD300	2	On the right side over the nuts on the bottom of fork leg at the front axle
	2	Left and right side rear footboard mounting bolts
	1	SILICONE over the exhaust mounting nut at the starter support bracket
HTD311	2	Over front gas tank mounting bolts left and right side
	2	Both sides fork tube drain plug
	2	On rear saddlebag to exhaust mounting plate bolts

HTD344	1	Left side SILICONE on the top of the kickstand mounting bolt
	2	On top of the rear shock mounting bolt on inner saddlebag
HTD365	1	SILICONE on the mounting bolt in the middle of the air cleaner cover
HTD400	2	Left and right side bottom engine guard SILICONE over mounting bolts
	1	SILICONE over the large nut on the right side rear brake pedal mount at pivot under the front floorboard
HTD420	2	Left side footboard mounting plate bolts near swing arm
	2	Right side footboard mounting plate bolts (IMPORTANT: On the lower bolt, because of the clearance between the exhaust pipe and the bolt, it is necessary to cut out 1/3 of the ribbed outer rim of the HTD420 and then SILICONE the part as you engage the piece from the top)
HTD500	4	On smooth bolts facing rear of bike connecting the saddlebag support bar to the support bracket
	4	On the top saddlebag support bracket mount bolts
HTD555	13	On windshield screws 9 on the front and 2 on each side
HTD600	3	SILICONE over exhaust nuts 1 on left side and 2 on right side (SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE)
HTD708	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD728	1	Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTD777	1	Snap black sleeve into chrome Hot Topper®, then slide the slotted sleeve over the left side hex axle nut and the Hot Topper® without the sleeve on the right side axle rod

ADDITIONAL OPTIONS NOT INCLUDED

HTD100	1	Right side SILICONE on the rear footboard mounting plate electrical clamp bolt
	2	SILICONE above the air cleaner on the top carburetor screws
HTD200	2	SILICONE over lower fork and bracket assembly mounting bolts below the rubber fork stops
HTD265	4	SILICONE over backside of rear footboard mounting screws
HTD400	2	On lower front inner frame to engine mount bolts behind front fender
HTD500	3	Lower front of frame below the regulator frame to engine mounting bolts
HTD555	1	Right side SILICONE below oil filler spout behind exhaust pipe on electrical bracket bolt
HTD600	2	On lower front inner frame to engine mount bolts behind front fender
	4	SILICONE on back side nut end of the smooth bolts facing the rear of bike connecting the saddlebag support bar to the support bracket
	1	SILICONE over acorn nut on horn cover
HTD820	1	SILICONE on engine oil filler cap