

ESPORT: FINISHING KIT FOR 1984-1999 SPORTSTER® KIT
INCLUDES 130 PIECES

HOT TOPPERS® are manufactured to fit American Standard fasteners.

There are some rare occasions where even though the nut or bolt is an American standard fastener, the Hot Topper® may not achieve a friction fit. In this case we recommend using a Napa clear silicone (Napa Auto part # 765-1481) to achieve a secure fitment. DO NOT USE ADHESIVE PRODUCTS to mount Hot Toppers®. The Napa product we recommend will allow for an easier removal if service is performed. We simply fill our cover with the necessary amount of silicone to achieve a firm hold on the fastener, yet beware that the silicone will expand when it sets up, so don't over fill our part. A little less goes a long way. Please email info@hottoppers.com or call our toll free USA number 877-446-8867 with any questions or comments.

HTD100	1	Brake line junction mounting bolt under triple tree
	1	SILICONE on the left side top of the shifter arm bracket
	3	Replace screws on side cover (electrical bracket) with supplied ¼ x 20 x ¾ allen bolts and press on Hot Toppers®
HTD200	2	Bolts on the top of upper triple tree
	4	On the handlebar clamp bolts (IMPORTANT: Check clearance on outer rim of all 4 bolts before you completely engage them and push them all down)
	2	Right side rear master cylinder
	1	Right side rear belt guard mounting bolt
	2	SILICONE on front and rear brake line to brake caliper mounting bolts
HTD211	1	SILICONE on rear master cylinder banjo bolt
	2	Regulator assembly to frame mounting nuts
HTD211	2	Ignition coil mounting bracket bolts
	4	In recessed allen bolts on both sides of front fork leg sliders that support front fender
HTD220	1	SILICONE in right side threaded hole on upper bracket of steering head bracket assembly
	5	Front left side brake disc mounting bolts (IMPORTANT: Install one Hot Topper® and rotate tire one complete rotation, make sure the Hot Topper® clears the fork leg)
HTD265	5	Front right side brake disc mounting bolts or front right side wheel hub
	1	SILICONE on oil filter mount bolt in front of engine
	1	SILICONE in the center of the choke knob
	4	SILICONE on the bolts on the sides of the upper and lower triple trees
	1	SILICONE on the front of the lower right side fork pinch bolt
HTD300	1	Front brake caliper mounting bolt
HTD311	4	On the inner front fender mounting nuts
	1	Left side bolt under the battery box
	2	Left side on the shifter rod bolts
	2	On the backside of the regulator to frame black mounting bolts

	1	SILICONE on upper brake master cylinder on the top of handlebars
HTD342	1	Over the top of the front fork steering stem bolt
HTD344	2	Upper front fork leg triple tree bottom side of handlebar clamp mounting bolts
	2	Rear bottom left and right side shock bolts
HTD355	5	Left side over rear sprocket mounting bolts and washers
HTD365	5	Over rear brake disc mounting bolts
	2	SILICONE over the upper mounting bolts on the top of the rear shocks
	1	SILICONE in recessed mounting bolt on left side rear fork
	1	SILICONE over recessed bolt on right side bottom of cylinders, between push rod lifter covers
HTD500	1	Right side headlight mounting bolt (Only on 883/1200 Custom)
	4	Footpeg mounting bolts (Only 2 on 883/883 Hugger®)
	4	Left side below rear fork
	2	Left side above the rear fork
	4	SILICONE on torx bolts on both sides of the rear fender struts
	2	SILICONE over rear brake caliper mounting bolts
HTD555	1	SILICONE on left side recessed allen bolt on upper bracket of steering head bracket assembly
HTD600	1	Right side back of lower fork leg pinch bolt
	1	Left side headlight mounting bolt (Only on 883/1200 Custom)
	4	Footpeg mounting nuts (Only 2 on 883/883 Hugger®)
	2	SILICONE over exhaust nuts on right side (SILICONE REQUIRED although our cover slides over nut, the stud prevents total engagement so add some SILICONE)
HTD703	1	Conversion kit!! Replace button torx screws on brake and clutch housings with supplied allen bolts and press on Hot Toppers®
HTD730	1	Conversion kit!! Replace button torx screws on derby and inspection covers with supplied allen bolts and press on Hot Toppers® (IMPORTANT: when replacing each button torx screw with allen bolt, make sure the allen bolt is the exact length of the button torx bolt. Also be sure to only change one bolt at a time so the gaskets do not loosen)
HTD777	1	Snap black sleeves into chrome Hot Toppers®, then slide the slotted sleeve over left side hex axle nut and the smooth sleeve over right side smooth axle rod
HTD810	1	SILICONE in circle indent on rear brake caliper
HTD820	1	SILICONE in circle indent on front brake caliper

ADDITIONAL OPTIONS NOT INCLUDED

HTD100	1	Right side SILICONE on the brake line on the sprocket cover behind the exhaust pipe above the brake master cylinder
	2	Left side SILICONE on brake line on rear fork and frame clamp bolts
	1	Right side SILICONE upper triple tree to brake line mounting bolt
HTD200	1	Right side SILICONE on the oil lines to starter motor clamp nut

HTD555	2	Right side SILICONE on the underside of rear fork to belt guard mounting bolts
HTD600	2	Axle adjuster bolts on backside of rear fork (NOTE: Length of stud may interfere with engagement of part)
	1	SILICONE over left side acorn nut on enrichment cable cover/ horn bracket