

HTD155 TWIN CAM FLH STARTER KIT INSTRUCTIONS

HTD100

- 10 PRIMARY COVER ALLEN BOLTS
- 5 RIGHT SIDE TOP OF TRANSMISSION COVER
- 1 OVER REGULATOR PLUG BOLT TOWARDS FRONT LEFT SIDE OF MOTOR
- 1 RIGHT SIDE FUEL INJECTION TEMPERATURE SENSOR BOLT ABOVE TRANSMISSION
- 6 RIGHT SIDE OVER TRANSMISSION KICKER COVER BOLTS
- 1 RIGHT SIDE TRANSMISSION CASE BOLT IN FRONT OF KICKER COVER
- 2 RIGHT SIDE OIL PUMP COVER BOLTS
- 10 RIGHT SIDE IGNITION/CAM COVER BOLTS
- 8 RIGHT SIDE TAPPET BLOCK BOLTS

HTD200

- 1 RIGHT SIDE STARTER BOLT
- 1 ON BATTERY CABLE
- 4 BOTTOM LEFT AND RIGHT SIDE OF KICKER COVER ON TRANSMISSION HOUSING

HTD288

- 9 MOUNT EACH ROCKER BOX COVER WITH CUT-OUT TOWARD BACKSIDE OF EACH BOLT WITH ABOUT 3 TEARDROP SIZE DABS OF *SILICONE* ON EACH STEM IN THE MIDDLE OF EACH CAP

HTD311

- 8 LEFT SIDE MOTOR CASE BOLTS UNDER FRONT TO REAR OF REAR CYLINDER
- 3 LEFT SIDE ON SIDE STAND MOUNTING BRACKET

HTD500

- 2 LEFT SIDE HEX BOLTS ON STABILIZER ARM FROM MOTOR TO FRAME, FRONT OF MOTOR
- 2 BOTH SIDES FRONT LOWER MOTOR MOUNTS
- 2 LEFT SIDE MOTOR MOUNT ABOVE HORN COVER, UNDER GAS TANK
- 2 BOTH SIDES OVER FRONT GAS TANK MOUNT SMOOTH TORX BOLTS

HTD600

- 4 UPPER AND LOWER LEFT AND RIGHT SIDE MOTOR TO TRANSMISSION HEX BOLTS
- 1 LOWER FRONT MOTOR MOUNT