

HTD188 TWIN CAM DYNA STARTER KIT INSTRUCTIONS

HTD100

- 12 OVER PRIMARY COVER ALLEN BOLTS
- 1 OVER REGULATOR PLUG BOLT ON LEFT SIDE FRONT OF MOTOR BY OIL FILTER
- 1 ON FUEL INJECTION TEMPERATURE SENSOR BOLT RIGHT SIDE JUST ABOVE TRANSMISSION
- 6 OVER TRANSMISSION KICKER COVER BOLTS RIGHT SIDE
- 1 OVER TRANSMISSION CASE BOLT JUST IN FRONT OF KICKER COVER RIGHT SIDE
- 2 OVER OIL PUMP COVER BOLTS RIGHT SIDE
- 6 ON TOP TRANSMISSION CASE
- 10 ON IGNITION/CAM COVER BOLTS RIGHT SIDE
- 8 OVER TAPPET BLOCK BOLTS RIGHT SIDE
- 4 ON LEFT SIDE ELECTRONIC BOX

HTD200

- 3 UNDER AND ON RIGHT AND LEFT SIDE OF KICKER COVER ON TRANSMISSION HOUSING

HTD220

- 1 *SILICONE* IN THE TIMING HOLE

HTD288

- 8 MOUNT (2) ON EACH ROCKER BOX COVER BOLT WITH CUT-OUT TOWARDS BACK (*SILICONE* REQUIRED AT STEM)

HTD300

- 2 ON FRONT LOWER MOTOR MOUNT ALLEN BOLTS

HTD311

- 8 ON LEFT SIDE MOTOR CASE HEX BOLTS UNDER FRONT TO REAR OF REAR CYLINDER ON THE LEFT SIDE OF MOTOR
- 1 ON SHIFT LEVER

HTD420

- 1 ON LEFT SIDE ONLY ON SWING ARM BOLT UNDER REAR OF PRIMARY COVER

HTD500

- 2 ON LEFT SIDE UPPER MOTOR MOUNT BOLTS ABOVE HORN UNDER GAS TANK
- 4 OVER LOWER FRONT MOTOR MOUNTS ON TOP AND ON RIGHT SIDE

HTD600

- 2 OVER LEFT SIDE OF LOWER FRONT MOTOR MOUNT NUTS
- 2 ON UPPER AND LOWER RIGHT SIDE MOTOR TO TRANSMISSION CONNECTION
- 1 LEFT SIDE UPPER MOTOR TO TRANSMISSION CONNECTION